
CO Sensors for Reformate Powered Fuel Cells

R. Mukundan, Eric Brosha, and D.R. Brown Research Staff

Fernando Garzon Team Leader

MST-11 Group

Los Alamos National Laboratory

Los Alamos NM 87545 USA

Objectives

- Reformate gas powered fuel cell systems require sensors for carbon monoxide level monitoring and feedback control
 - A high temperature sensor is required for measurement of 0.1 to 2% CO in reformate gas for fuel processor control
 - A low temperature sensor for measuring 10-100 ppm range concentrations for stack poisoning control


Approach

- Two different electrochemical sensor types are being investigated for high and low temperature CO sensing
 - An oxide solid electrolyte device is being developed for the high temperature application
 - Yttria stabilized zirconia oxygen ion conducting electrolyte
 - Strontium yttrium zirconium perovskite proton conducting electrolyte
 - Low temperature amperometric device based on CO inhibition of hydrogen oxidation kinetics
 - Perfluorosulfonic acid polymer electrolyte
 - Inorganic acid electrolyte


Approach

Low temperature Amperometric Sensor

- Use Nafion as the proton conducting membrane
- Use Pt or Ru electrode as working electrode
 - is sensitive to CO poisoning
- Use Pt-Ru electrode as a counter electrode
 - more tolerant to the presence of CO



Project Timeline




Accomplishments

- Effect of CO on typical fuel cell electrode loadings
 - Working Electrode
 - Pt/C/Nafion : 0.22mg/cm² of Pt or
 - Ru/C/Nafion : 0.12mg/cm² of Ru
 - Reference Electrode
 - Pt/Ru/C/Nafion : 0.25mg/cm² of Pt/Ru(50/50)alloy
 - Electrolyte
 - Nafion 1135


Accomplishments

- Both the Pt/C and the Pt/Ru/C electrodes are good at hydrogen oxidation and both of them get poisoned by the CO
- The CO poisoning is not easily reversible
 - Recovery takes hours without air bleeding



Accomplishments

- While the Pt/C electrode is good at hydrogen oxidation the Ru/C electrode is not very efficient at H_2 oxidation
- Both the electrodes get poisoned by the CO, the Ru/C electrode to a lesser extent
- The CO from the Ru/C electrode can be easily stripped at voltages $< -0.5V$ (see inset)
- The CO poisoning is not easily reversible on the Pt/C electrode
 - Recovery takes hours without air bleeding




Accomplishments

- Effect of CO on sensor response at high catalyst loadings
 - Working Electrode
 - Pt/Nafion : $\approx 10\text{mg/cm}^2$ of Pt or
 - Ru/Nafion : $\approx 10\text{mg/cm}^2$ of Ru
 - Reference Electrode
 - Pt/Ru/Nafion : $\approx 10\text{mg/cm}^2$ of Pt/Ru(50/50)alloy
 - Electrolyte
 - Nafion 117


Accomplishments

- Both the Pt and Pt/Ru alloy electrodes are good for H_2 oxidation
- There is very little effect of CO on the Pt/Ru alloy electrode.
 - This electrode could serve as a pseudo-reference electrode
- The Pt electrode gets poisoned by the CO which can easily be cleaned at voltages $> 0.4V$




Accomplishments

- The extent of poisoning on the Pt electrode can be used to give a useful sensor response
- The current at 0.3V decreases from 15mamps to <5mamps when the CO content in the H₂ stream is increased from 0 to 50ppm.
- The final CO can be cleaned by applying a 0.8V potential for approx. one minute




Accomplishments

- Both the Pt and Ru electrodes are good for H_2 oxidation
- The Pt electrode gets poisoned by the CO which can easily be cleaned at voltages $> 0.4V$
- The Ru electrode also gets poisoned by the CO and can be cleaned at voltages $< -0.6V$
 - The clean up on this electrode appears to be slower than that of the Pt/Ru alloy electrode



Accomplishments

- The extent of poisoning on the Ru electrode can be used to give a useful sensor response
- The current at -0.5V decreases from -30mamps to -18mamps when the CO content in the H₂ stream is increased from 0 to 50ppm.
- The final CO can be cleaned by applying a -0.8V potential for approx. one minute



Future Plans

- Study the stability of these sensors at room temperature
- Increase the operating temperature of these sensors to 80-90°C
- Study water management issues in these sensors and stabilize the sensor response at elevated temperatures
- Optimize electrodes and electrolyte to get maximum sensitivity to CO

Acknowledgements

- DOE-OAAT for Funding
- Francisco Uribe for help with CV's
- Bryan Pivovar and Piotr Zelenay for insights and assistance with the Pt-Ru membranes
- Judith Valerio for assistance with the carbon-supported electrodes